



# TTS Transit (Fall 2024)

## Boot Manufacturer Size Guide

Find your Boot Sole Length (BSL) usually located on the heel of your boot, and then match your BSL to the corresponding brand chart below. This will indicate the size of heel assembly required for your desired performance setting.

**Front wire position = most neutral.**

**Back wire position = most active.**

	LARGE (LONG TRAVEL CARTRIDGES)			SMALL (REGULAR TOUR CARTRIDGES)		
<b>Wire Position:</b>	Front	Middle	Back	Front	Middle	Back
<b>BSL Range:</b>	280-326	290-336	300-346	264-304	274-314	284-324

SCARPA	LARGE			SMALL			NEW TX PRO
	Front	Middle	Back	Front	Middle	Back	
BSL							
275				X	X		273
283	X			X	X		282
291	X	X		X	X	X	290
299	X	X		X	X	X	299
307	X	X	X		X	X	308
316	X	X	X			X	317
325	X	X	X			X	325
333		X	X				334

SCOTT	LARGE			SMALL		
	Front	Middle	Back	Front	Middle	Back
BSL						
276				X	X	
286	X			X	X	X
296	X	X		X	X	X
306	X	X	X		X	X
316	X	X	X			X
326	X	X	X			
336		X	X			
346			X			

CRISPI	LARGE			SMALL		
	Front	Middle	Back	Front	Middle	Back
BSL						
285	X			X	X	X
296	X	X		X	X	X
307	X	X	X		X	X
315	X	X	X			X
327	X	X	X			
335		X	X			